




# ASSEMBLY INSTRUCTIONS



Combination Valve		
	2223-000	VALVE, COMBINATION, COMPLETE
	2223-000-99	VALVE, COMBINATION, REPAIR KIT, INCLUDES # 4, 8, 9, 10, 13, 16 & 18
1	2223-000-01	VALVE, COMBINATION, CAP
2	2223-000-02	VALVE, COMBINATION, PINCH RAM
3	2223-000-03	VALVE, COMBINATION, UPPER ROD GUIDE, INCLUDES SEAL(#4) AND BUSHING
4	2223-000-04	VALVE, COMBINATION, SEAL, UPPER ROD
5	2223-000-05	VALVE, COMBINATION, SPRING
6	7010-507-16	VALVE, COMBINATION, BOLT 3/8" x 6" W/WASHER
7	2223-000-07	VALVE, COMBINATION, CYLINDER
8	2223-000-08	VALVE, COMBINATION, O-RING, SHAFT
9	2223-000-09	VALVE, COMBINATION, SNAP RING
10	2223-000-10	VALVE, COMBINATION, SEAL, LOWER ROD
11	2223-000-11	VALVE, COMBINATION, PISTON
12	2223-000-12	VALVE, COMBINATION, SHAFT
13	2223-000-13	VALVE, COMBINATION, SEAL, PISTON
14	7017-507-01	VALVE, COMBINATION, NUT, 3/8"
15	2223-000-15	VALVE, COMBINATION, LOWER ROD GUIDE, INCLUDES SEAL(#10) AND BUSHING
16	2223-000-16	VALVE, COMBINATION, O-RING, LOWER ROD GUIDE
17	2223-000-17	VALVE, COMBINATION, BASE
18	2223-000-18	VALVE, COMBINATION, PLUG ASSEMBLY
19	2014-300	VENT, 1/8"
20	4203-500-00	SWIVEL 90°, 1/8"MNPT X 1/8"F
21	4203-502-02	SWIVEL 90°, 1/4"MNPT x 1/4"F