




# ASSEMBLY INSTRUCTIONS

## Fast-Stop™ Pinch Valve Control Connections



**From  
Control  
Valve**

**To  
Metering  
Valve**

**To  
Automatic  
Air Valve**